

Palm Software Installation Instructions

Needed to complete this operation:

- Palm handheld computer (*see list of compatible models at the end of this document).
- Palm Desktop software installed on PC and first HotSync completed (consult the Palm documentation and software included with handheld).
- Either of the following cables:
 - For older model Palm devices (*see list of compatible models):
 - Black Palm Interface Cable (415044 available from Stanley).
 - For new model Palm devices (*see list of compatible models):
 - Yellow Palm Interface Cable (516864 available from Stanley).
- File '713960H(MC521Toolbox_v1.1.6).prc' and/or '713944D(M40Express_v3.05).prc'.

To install the software on the card, first save the files '713960H(MC521Toolbox_v1.1.6).prc' and/or '713944D(M40Express_v3.05).prc' to the hard drive.

Removing older programs:

Before installing the new programs, remove any older versions that may be on the card or the device.

Follow these steps:

- Tap on the menu button.
- Select 'Delete' from the 'App' menu.
- Select 'Device' from list at top of page to delete files on the device, and select 'Card' from list at top of page to delete files on the card.
- Scroll through the list and delete the following file from both if present:
 - 'EXPRESS'.
 - 'ToolBox'.

Follow these steps to transfer the files to the card using HotSync:

- Find and double click on the files that were just saved.
- Add the files to the memory card (this will differ depending on the Palm Desktop Software version; consult the documentation that comes with the Palm).
- Begin HotSync to transfer file to card.

Follow these steps to transfer the files to the card using a SD/MMC card reader:

- Find the files that were just saved.
- Add the files to the memory card in the \Palm\Launcher\ folder.

To verify that the latest version software is on the card:

For MC521Toolbox:

- Insert card into the Palm device, go to the card screen of the device and tap on the 'MC521 Tool Box' icon.
- 'Version 1.1.6' should be displayed at the top of the screen. This verifies that the latest Palm software (Rev. H) is installed on the card.

For M40Express:

- Insert card into the Palm device, go to the card screen of the device and tap on the 'StanleyM40Express' icon.
- On the next screen, tap on the letter 'i' at the top right of the screen. Verify that 'Version 3.05' (Rev. D) is displayed on the This Program screen.

To use the program to setup the controller:

For MC521Toolbox:

- Refer to MC521 manual 204003 for slide doors and MC521 manual 204027 for swing and Bifold doors.

For M40Express:

- Refer to Stan-Vision manual 203975.

***Compatible Palm Models:**

For these old models use Black Palm Interface Cable (415044 available from Stanley)

- M Series: m125, m130, m500, m505, and m515.
- I Series: i705.
- Zire Series: Zire71.
- Tungsten Series: Tungsten C, Tungsten T2, Tungsten T3, and Tungsten W.

For these new models use Yellow Palm Interface Cable (516864 available from Stanley)

- Tungsten Series: Tungsten E2 and Tungsten TX.
- Treo Series: Treo 650.
- Life Drive Series: Life Drive.